Alphabetical index

| п |
|---|
| |
| |
| |

| A/C |
|-----------------------------------|
| Air conditioning filter579 |
| Automatic air conditioning |
| system244, 253, 262, 272 |
| Front air conditioning |
| system244, 253, 262 |
| Rear air conditioning system272 |
| ABS217 |
| ACCESSORY mode154 |
| AFS183 |
| Adaptive front-lighting system183 |
| Air conditioning filter579 |
| Air conditioning system |
| Air conditioning filter579 |
| Front air conditioning |
| system244, 253, 262 |
| Rear air conditioning system272 |
| Airbags |
| Airbag operating conditions114 |
| Airbag precautions for your |
| child119 |
| Airbag warning light628 |
| Curtain shield airbag operating |
| conditions115 |
| Curtain shield airbag |
| precautions119 |

Front passenger occupant

Side airbag operating

airbags......123
Proper driving posture.......108, 119

| Alarm105 |
|------------------------------------|
| Antenna287 |
| Anti-lock brake system217 |
| Armrest488 |
| Ashtrays477 |
| Audio input302, 356 |
| Audio system |
| Antenna287 |
| Audio input302, 356 |
| Audio visual input405 |
| AUX adapter302, 356 |
| A/V input adapter405 |
| CD player/changer288, 313 |
| DVD player328, 373, 374 |
| MP3/WMA disc294, 321 |
| Optimal use300, 352 |
| Portable music player302, 356 |
| Radio284, 308 |
| Rear seat audio system357 |
| Rear seat entertainment |
| system363 |
| Steering wheel audio switch303 |
| Audio visual input405 |
| Automatic air conditioning system |
| Air conditioning filter579 |
| Front air conditioning |
| system244, 253, 262 |
| Rear air conditioning system 272 |
| Automatic headlight leveling |
| system184 |
| Automatic light control system 182 |
| Automatic transmission |
| Automatic transmission158 |
| If the shift lever cannot be |
| shifted from "P"649 |
| "S" mode160 |
| ALIX adapter 302 356 |

| | A/V input adapter405 | Installing CRS with lower |
|---|---|-----------------------------------|
| | | anchors135 |
| В | Back-up lights | Installing CRS with seatbelts137 |
| | Wattage677 | Installing CRS with top straps140 |
| | Battery | Child safety |
| | Checking561 | Airbag precautions119 |
| | If the vehicle has discharged | Battery precautions562, 659 |
| | battery657 | Child restraint system129 |
| | Preparing and checking | Child-protectors49 |
| | before winter232 | How your child should wear |
| | Bluetooth [®] 409 | the seatbelt84 |
| | Brake | Installing child restraints134 |
| | Fluid559 | Moon roof precautions99 |
| | Brake hold167 | Power window lock switch94 |
| | Parking brake164 | Power window precautions96 |
| | Brake assist217 | Removed electronic key battery |
| | Brake hold167 | precautions583 |
| | | Seat belt comfort guide82 |
| С | Care | Seat belt extender precautions86 |
| | Exterior530 | Seat belt precautions85 |
| | Interior533 | Seat heater precautions487 |
| | Seat belts | Trunk precautions56 |
| | Cargo capacity227 | Child-protectors49 |
| | Cargo hooks503 | Cigarette lighter478 |
| | CD changer288, 313 | Cleaning |
| | CD player288, 313 | Exterior530 |
| | Chains232 | Interior 533 |
| | Child restraint system | Seat belts534 |
| | Booster seats, definition129 | Climate control seat484 |
| | Booster seats, installation137 | Climate control seat filter581 |
| | Convertible seats, definition129 | Clock474 |
| | | Coat hooks501 |
| | Convertible seats, installation 137 | Coin holder460 |
| | Front passenger occupant classification system124 | Compass 512 |
| | - | Condenser559 |
| | Infant seats, definition129 | Console box464 |
| | iriidrit sedts, iristaliation13/ | Cool box466 |
| | | 705 |

| | Cooling system |
|---|---------------------------------------|
| | Engine overheating660 |
| | Cornering assist sensors203 |
| | Cruise control |
| | Cruise control190 |
| | Dynamic radar cruise control193 |
| | Cup holders462 |
| | Curtain shield airbags110 |
| | Customizable features692 |
| D | Daytime running light system183 |
| | Defogger |
| | Rear window279 |
| | Side mirrors |
| | Dimensions |
| | Dinghy towing |
| | Display |
| | Multi-information display178 |
| | Touch screen236 |
| | Trip information179 |
| | Warning message636 |
| | Do-it-yourself maintenance542 |
| | Door courtesy lights |
| | Door courtesy lights453 |
| | Wattage677 |
| | Door pockets461 |
| | Doors |
| | Door glasses94 |
| | Door lock |
| | Side mirrors91 |
| | Driver's seat belt reminder light 629 |
| | Driving |
| | Correct posture108 |
| | Procedures144 |
| | Driving position memory70 |
| | DVD player328, 373, 374 |

| Electric power steering217 |
|----------------------------------|
| Electronically modulated air |
| suspension212 |
| Electronic key |
| If the electronic key does not |
| operate properly653 |
| Emergency flashers |
| Switch616 |
| Emergency, in case of |
| If the electronic key does not |
| operate properly653 |
| If the engine will not start647 |
| If the parking brake cannot be |
| released650 |
| If the shift lever cannot be |
| shifted from "P"649 |
| If the vehicle has discharged |
| battery657 |
| If the warning buzzer sounds627 |
| If the warning light turns on627 |
| If the warning message is |
| displayed636 |
| If you have a flat tire639 |
| lf you lose your keys652 |
| If you think something is |
| wrong623 |
| lf your vehicle becomes stuck663 |
| If your vehicle needs to be |
| towed617 |
| If your vehicle overheats660 |

| Engine | |
|------------------------------|-----|
| Accessory mode | 154 |
| Compartment | 548 |
| Engine switch | 154 |
| Hood | 545 |
| How to start the engine | 154 |
| Identification number | 667 |
| If the engine will not start | 647 |
| Ignition switch | 154 |
| Overheating | 660 |
| Engine compartment cover | 550 |
| Engine coolant | |
| Capacity | 671 |
| Checking | 557 |
| Preparing and checking | |
| before winter | 232 |
| Engine coolant temperature | |
| gauge | 171 |
| Engine immobilizer system | 103 |
| Engine oil | |
| Capacity | 670 |
| Checking | 553 |
| Preparing and checking | |
| before winter | 232 |
| Engine oil maintenance data | 556 |
| EPS | 217 |
| Event data recorder | 625 |
| | |

| Le | - 00 |
|---------------------------------|-------------|
| First-aid kit storage belt | |
| Floor mat | 502 |
| Fluid | |
| Brake | |
| Washer | 564 |
| Fog lights | |
| Switch | 185 |
| Wattage | 677 |
| Footwell lighting | 453 |
| Front fog lights | |
| Switch | 185 |
| Wattage | 677 |
| Front passenger occupant | |
| classification system | 124 |
| Front passenger's seat belt | |
| reminder light | 629 |
| Front passenger's seat position | |
| memory | 75 |
| Front seats | |
| Adjustment | 60 |
| Driving position memory | 70 |
| Seat position memory | |
| Front turn signal lights | |
| Wattage | 677 |
| Fuel | |
| Capacity | 669 |
| Fuel gauge | |
| Fuel pump shut off system | |
| Information | |
| Refueling | |
| Fuel door | |
| Fuel filler door | |
| Fuel pump shut off system | |
| | E04 |

| Garage door opener | 506 | I/M test | 541 |
|------------------------------|-----|---------------------------|-----|
| Gauges | 171 | Identification | |
| Glove box | 459 | Engine | 667 |
| | | Vehicle | 667 |
| Hands-free system | | Ignition switch | 154 |
| (for cellular phone) | 409 | Illuminated entry system | 453 |
| Hazard lights | | Indicator lights | 174 |
| Switch | 616 | Initialization | |
| Head restraints | | Items to initialize | 696 |
| Adjustment | 79 | Inside rear view mirror | 90 |
| Headlight aim | | Interior lights | |
| Headlight cleaner | | Interior lights | 453 |
| Headlights | | Switch | 454 |
| Discharge headlight | | Wattage | 677 |
| precautions | 613 | | |
| Replacing light bulbs | | Jack | |
| Switch | | Positioning a floor jack | 546 |
| Wattage | | Vehicle-equipped jack | |
| Heaters | | Jack handle | |
| Seat heaters | 484 | | |
| Side mirrors | | K Keyless entry | 45 |
| Steering wheel | | Keys | |
| Height control | | Electronic key | 28 |
| Electronically modulated air | | Engine switch | |
| suspension | 212 | If the electronic key doe | |
| Hill-start assist control | | operate properly | |
| Hood | 545 | If you lose your keys | |
| Hooks | | Key number | |
| Cargo | 503 | Keyless entry | |
| Coat | | Keys | |
| Shopping bag | | Mechanical key | |
| Horn | | Wireless remote contro | |

| L | Lexus link system | 516 | | Micro dust and | |
|---|------------------------------|-------|---|-----------------------------|----------|
| | Light bulbs | | | pollen filter248, 25 | 57, 268 |
| | Replacing | 603 | | Mirrors | |
| | Wattage | 677 | | Inside rear view mirror | 90 |
| | Lights | | | Side mirror heaters | 279 |
| | Door courtesy lights | 453 | | Side mirrors | 91 |
| | Emergency flasher switch | 616 | | Vanity mirrors | 473 |
| | Fog light switch | 185 | | Moon roof | |
| | Hazard light switch | 616 | | MP3 disc294, 3 | 321, 377 |
| | Headlight switch | 182 | | Multi-information display | 178 |
| | Interior light switch | 454 | | | |
| | Outer foot lights | 453 | Ν | Noise from under vehicle | 24 |
| | Overhead courtesy light | 453 | | | |
| | Personal light switch | 454 | 0 | Odometer | 17 |
| | Replacing light bulbs | 603 | | Oil | 17 |
| | Shift lever lighting | 453 | | Engine oil | 553 |
| | Turn signal lever | 163 | | Opener | |
| | Vanity lights | 473 | | Fuel filler door | 100 |
| | Wattage | 677 | | Hood | |
| | Load capacity | 230 | | Trunk | |
| | | | | Outer foot lights | |
| М | Maintenance | | | Outer foot lights | 453 |
| | Do-it-yourself maintenance | 542 | | Wattage | |
| | General maintenance | 538 | | Outside rear view mirrors | |
| | Maintenance data | 666 | | Adjusting and folding | 91 |
| | Maintenance requirements. | 536 | | Mirror position memory | |
| | Meter | | | Outside temperature display | |
| | Instrument panel light contr | ol172 | | Overhead console | 470 |
| | Meters | 171 | | Overhead courtesy lights | |
| | | | | Overhead courtesy lights | 453 |
| | | | | Wattage | |
| | | | | Overheating, Engine | |
| | | | | 3, 3 | |

| Р | Parking assist sensors203 | Rear view mirror |
|---|-----------------------------------|--------------------------------|
| | Parking brake164 | Compass512 |
| | Parking lights | Rear view monitor system214 |
| | Replacing light bulbs603 | Rear window defogger279 |
| | Switch182 | Replacing |
| | Wattage677 | Electronic key battery582 |
| | PCS223 | Fuses584 |
| | Penlight640 | Light bulbs603 |
| | Personal lights | Tires639 |
| | Switch454 | Reporting safety defects for |
| | Power outlet480 | U.S.A. owners698 |
| | Power windows94 | |
| | Pre-collision system223 | S Seat belts |
| | | Adjusting the seat belt82 |
| R | Radar cruise control193 | Automatic locking retractor 83 |
| | Radiator559 | Child restraint system |
| | Radio284, 308 | installation134 |
| | RDS286 | Cleaning and maintaining |
| | Rear seat | the seat belts534 |
| | Seat adjustment63, 66 | Emergency locking retractor 83 |
| | Seat position memory77 | How to wear your seat belt81 |
| | Rear seat entertainment system363 | How your child should wear |
| | Rear seat relaxation system489 | the seat belt84 |
| | Rear sunshade493 | Pregnant women, |
| | Rear turn signal lights | proper seat belt use83 |
| | Replacing light bulbs603 | Reminder light629 |
| | Wattage677 | Seat belt extenders84 |
| | | Seat belt pretensioners82 |
| | | Seat heaters484 |
| | | Seat position memory |
| | | Seating capacity230 |
| | | |
| | | |

| Seats |
|--|
| Adjustment60, 63, 66 |
| Adjustment |
| precautions 62, 65, 69 |
| Child seats/child restraint |
| system installation134 |
| Cleaning533 |
| Climate control484 |
| Climate control seat484 |
| Driver's seat position memory 70 |
| Front passenger's seat |
| position memory75 |
| Head restraint79 |
| Properly sitting in the seat108 |
| Rear seat position memory77 |
| Rear seat relaxation system489 |
| Seat heaters484 |
| Seat position memory70, 75, 77 |
| |
| Service reminder indicators174 |
| Service reminder indicators174 Shift lever |
| |
| Shift lever Automatic transmission158 If the shift lever cannot be |
| Shift lever Automatic transmission |
| Shift lever Automatic transmission158 If the shift lever cannot be |
| Shift lever Automatic transmission158 If the shift lever cannot be shifted from "P"649 |
| Shift lever Automatic transmission |

| Spare tire | |
|-------------------------------|------|
| Inflation pressure | .573 |
| Storage location | 639 |
| Spark plug | .672 |
| Specifications | .666 |
| Speedometer | 171 |
| Steering wheel | |
| Adjustment | 88 |
| Audio switches | 303 |
| Heated steering wheel | .482 |
| Steering wheel position | |
| memory | 70 |
| Storage feature | |
| Stuck vehicle | |
| If your vehicle becomes stuck | 663 |
| Sun visors | .472 |
| Sunshades | |
| Rear | .493 |
| Rear door | 496 |
| Roof | 98 |
| Switch | |
| "ECT" switch | 160 |
| Emergency flasher switch | 616 |
| Engine switch | 154 |
| Fog light switch | 185 |
| Hazard light switch | 616 |
| Heated steering wheel switch | .482 |
| Ignition switch | |
| Light switches | 182 |
| Parking brake switch | 164 |
| Power door lock switch | 48 |
| Power trunk lid | 53 |
| Power trunk opener and closer | 53 |
| Power window switch | 94 |
| Window lock switch | |
| Wipers and washer switch | |

| Tachometer171 | Towing |
|---------------------------------|-----------------------------------|
| Tail lights | Dinghy towing237 |
| Switch182 | Emergency towing617 |
| Theft deterrent system | Trailer towing236 |
| Alarm105 | TRAC217 |
| Engine immobilizer system 103 | Traction control217 |
| Theft prevention labels107 | Trip meter171 |
| Tire inflation pressure573 | Trunk |
| Tire information | Extending a space499 |
| Glossary686 | Opener53 |
| Size683 | Closer53 |
| Tire identification number682 | Trunk light |
| Uniform tire quality grading684 | Wattage677 |
| Tires | Turn signal lights |
| Chains232 | Replacing light bulbs603 |
| Checking565 | Switch163 |
| If you have a flat tire639 | Wattage677 |
| Inflation pressure573 | |
| Inflation pressure sensor566 | V Vanity lights |
| Information681 | Vanity lights473 |
| Replacing639 | Wattage677 |
| Rotating tires565 | Vanity mirrors 473 |
| Size675 | Variable gear ratio steering217 |
| Snow tires232 | VDIM217 |
| Tire pressure warning | Vehicle dynamics integrated |
| system565, 629 | management217 |
| Tools639 | Vehicle identification number 667 |
| Total load capacity230 | Vehicle stability control217 |
| Touch screen236 | VGRS217 |
| | VSC217 |
| | |

| warning buzzers | |
|----------------------------|------|
| Brake system | 627 |
| Open door | .629 |
| Seat belt reminder | .629 |
| Warning lights | |
| Anti-lock brake system | .628 |
| Brake assist system | .628 |
| Brake system627, | 629 |
| Charging system | 627 |
| Electric power steering | .628 |
| Electronic engine control | |
| system | .628 |
| Low fuel level | .629 |
| Low tire pressure | .629 |
| Malfunction indicator lamp | .628 |
| Master warning light | .629 |
| Open door | .629 |
| Pre-collision system | .628 |
| Pretensioners | .628 |
| Seat belt reminder light | .629 |
| SRS airbags | .628 |
| Tire pressure | .629 |
| Warning messages | 636 |
| Washer | |
| Checking | .564 |
| Preparing and checking | |
| before winter | 232 |
| Switch | 186 |
| Washing and waxing | 530 |
| Weight | |
| Cargo capacity | 227 |
| Load limits | .230 |
| Weight | .666 |

| 77 |
|----|
| 94 |
| 94 |
| |
| 94 |
| 79 |
| 36 |
| 30 |
| 36 |
| |
| 32 |
| 77 |
| |